Electrolux Service

ELECTROLUX OUTDOOR PRODUCTS

brand	**FLYMO**

date	JUN/03	*SHEET 1/2*

Model	Prefix
POWER TRIM 700 EURO	01

Product number
953900332

FIGURE 1



FIGURE 2

Electrolux Service

ELECTROLUX OUTDOOR PRODUCTS

brand	**FLYMO**

date	JUN/03	*SHEET 2/2*

Model	Prefix	Product number
POWER TRIM 700 EURO	01	**953900332**

FIGURE 1

	pos		P/N McC	P/N ELX	Q.ty	DESCRIPTION
C	1		242414	538242414	1	Motor
	2		227123	538227123	1	Ring
	3		241660	538241660	1	Cable+Plug
	4		241570	538241570	1	Metal guard
	5		242381	538242381	1	Right shield
	6		242380	538242380	1	Left Shield
C	7		242379	538242379	1	Cap
	8		240862	538240862	7	Screw
	9		241571	538241571	1	Wires ass'y
	10	•	240794	538240794	1	Radio int. Suppressor
	11	•	241814	538241814	1	Rubber cap
	12		242372	538242372	1	Shaft
	13		324295	538324295	1	Snap button
C	14		242419	538242419	1	Grass shield
	15		324316	538324316	1	Screw
	16		235248	538235248	1	Washer
C	17		242375	538242375	1	Push & turn button
C	18		241573	538241573	1	Spring
C	19		242374	538242374	1	Push & turn button
C	20		242384	538242384	1	Handle
C	21		242377	538242377	1	Release button
C	22		242323	538242323	1	Disengaging lever
C	23		241574	538241574	1	Spring
	24		240862	538240862	10	Screw
C	25		241576	538241576	1	Switch
C	26		242378	538242378	1	Micro Switch lever
	27		242383	538242383	1	Right Crankcase
	28		242382	538242382	1	Left Crankcase
	29		241052	538241052	1	Clamp
	30		241051	538241051	1	Fair lead
	31		229791	538229791	2	Screw

FIGURE 2

C	1		242416	538242416	1	String Head
A	2	•	248750	538248750	1	Spool+Line
B	3	•	248751	538248751	1	String Head Cover

A= ALTA ROTAZIONE	A=HIGH MOVING	A=HAUTE DEMANDE	A=GROßE NACHFRAGE
B=MEDIA ROTAZIONE	B=MEDIUM MOVING	B=MOYENNE DEMANDE	B=MITTELMAEßIGE
C=BASSA ROTAZIONE	C=SLOW MOVING	C=BASSE DEMANDE	C=WENIGE NACHFRAGE